

Pacific Performance Engineering
303 N Placentia Ave.
Fullerton, CA 92831

www.ppediesel.com

Technical Support: (714) 985-4825
Fax: (714) 985-9907
Email: sales@ppediesel.com

DURAMAX DUAL 145 AMP ALTERNATOR KIT

Installation Guide

Parts Identification





1. Remove wheel-well liner clips on the front left side of the truck wheel-well. Remove wheel-well liner.



4. Open back of connector by squeezing its sides with your fingers and pulling out.



2. Remove plastic cover from PCM by releasing locking tabs as shown



5. Push in white tab on both sides to remove blue connector cover so that pin can be inserted fully.



3. Take out the PCM.



6. Insert auxiliary alternator charge wire in jack #32 on the blue connector.